



## TECHNICAL RECOMMENDATIONS:




UV  
PROTECTED SIDE

1. PROTECT THE SHEETS BY THE SUN AND RAIN
2. INSTALL THE SHEETS ALWAYS WITH THE UV PROTECTED LAYER FACING OUTWARDS




3. MULTIWALL POLYCARBONATE SHEETS CAN NOT BE WALKED UPON
4. DO NOT WALK ONTO THE SHEETS AT ANY TIME. FOLLOW SAFETY REGULATIONS AND SAFE METHODS OF INSTALLATION

POLYCARBONATE SUFFER THE CHEMICAL ATTACK OF SOME PRODUCTS. THEREFORE:




5. USE ONLY COMPATIBLE CLEAR SILICONE FOR THE SEALING
6. USE ONLY WATER AND MILD DETERGENTS FOR THE CLEANING

THE SHEETS ARE SUPPLIED TO THE EXACT LENGTH REQUIRED WITH THERMOSEALED ENDS



CUTTING:




DRILLING:

7. CUTTING OF THE SHEETS CAN BE EXECUTED ON SITE BY MEANS OF A HACK SAWING MACHINE (1) OR OF A CUTTER (2). SEAL THE OPEN CELLS AFTER THE CUTTING.




8. DRILLING OF THE SHEETS CAN BE EXECUTED ON SITE BY MEANS OF A DRILL AND SUITABLE HEADS. THE HOLE MUST BE 3mm WIDER THAN SCREW GAUGE OR A SLOT ALONG THE LENGTH

FIXING:



9a THE FIXING MUST BE EXECUTED PERPENDICULAR TO THE SHEET  
9b DO NOT OVERTIGHTEN THE SCREWS SO AS TO NOT DAMAGE THE SHEET AT THE FIXING POINT

10. LOADINGS AND SPACINGS  
CHECK OUR TECHNICAL LITERATURE TO DETERMINE LOADING  
AND SPACING OF THE WHOLE SYSTEM



**polypiu**  
SOLUTIONS IN POLYCARBONATE  
**SMARTPIU'**

Wave 76/18

### MULTIPLE SHEET APPLICATION

