



TECHNICAL RECOMMENDATIONS:




1. PROTECT THE SHEETS BY THE SUN AND RAIN
2. INSTALL THE SHEETS ALWAYS WITH THE UV PROTECTED LAYER FACING OUTWARDS




3. MULTIWALL POLYCARBONATE SHEETS CAN NOT BE WALKED UPON
4. DO NOT WALK ONTO THE SHEETS AT ANY TIME. FOLLOW SAFETY REGULATIONS AND SAFE METHODS OF INSTALLATION

POLYCARBONATE SUFFER THE CHEMICAL ATTACK OF SOME PRODUCTS. THEREFORE:



5. USE ONLY COMPATIBLE CLEAR SILICONE FOR THE SEALING
6. USE ONLY WATER AND MILD DETERGENTS FOR THE CLEANING


THE SHEETS ARE SUPPLIED TO THE EXACT LENGTH REQUIRED AND SEALED AT THE ENDS WITH AN ALUMINIUM FOIL TAPE.




7. CUTTING OF THE SHEETS CAN BE EXECUTED ON SITE BY MEANS OF A HACK SAWING MACHINE (1) OR OF A CUTTER (2). SEAL THE OPEN CELLS AFTER THE CUTTING.

PROTECTIVE FILM:


PROFILES:



8. TAKE OFF THE PROTECTIVE FILM BEFORE THE INSTALLATION
9. SEAL THE OPEN CELLS WITH AN ADHESIVE ALUMINIUM TAPE




10. PROTECT THE SEALING WITH AN UPPER AND A LOWER PROFILE
- 10.a. LOWER PROFILES MUST BE DRILLED FOR WATER DRAINING



LOADINGS AND SPACING:

11. CHECK OUR TECHNICAL LITERATURE TO DETERMINE LOADINGS AND SPACING OF THE WHOLE SYSTEM



A PANELPIU' 500/16/20/25

500mm SHEET WIDTH

UV PROTECTED SIDE

16-20-25

B LOWER PROFILE

C UPPER PROFILE


D SIDE PROFILE (in 2 pieces)

E GASKET

Aluminium

F CLAMP (ACCESSORY)

Fixing on middle purlin



See point 11. for spacing and loading

polypiu
SOLUTIONS IN POLYCARBONATE
PANELPIU
500/16-20-25